


Gazell

Assembly instruction P44-1
Monteringsanvisning P44-1
Montageanleitung P44-1



Efterdra alla skruvar efter en tids användning.
Tighten all screws after some times use.
Alle Schrauben nach einiger Zeit nachziehen