


Montageanleitung
Montážny návod

POINT


Type/Typ

BP-80/120/180


MN 144/180
















Typ BP-80




Typ BP-120




Typ BP-180

	
Typ BP-80/120	Typ BP-180
1  $\varnothing 8 \times 35$ x4	 $\varnothing 8 \times 35$ x5
2  $\varnothing 7 \times 50$ x5	 $\varnothing 7 \times 50$ x6
3  $\varnothing 6,3 \times 11$ x4	 $\varnothing 6,3 \times 11$ x6
4  $\varnothing 10 \times 50$ x2	 $\varnothing 10 \times 50$ x3
5  $\varnothing 35$ x2	 $\varnothing 35$ x3
6  $\varnothing 10 \times 50$ x2	 $\varnothing 10 \times 50$ x3
* NICHT BEINHALTET IM BESCHLAGBEUTEL! * NIE JE SÚČASŤOU KOVANIA!	


SERVISKARTE / SERVISNÁ KARTA



Typ BP-80







Typ BP-120







Typ BP-180

1



ALTERNATÍVA / ALTERNATIVE 01



ALTERNATÍVA / ALTERNATIVE 02



2



DECODOM, spol. s r.o.



Pílska 7

955 13 Topoľčany





Slovenská republika / Slowakei / Slovak republic

info@decodom.sk

Höheneinstellung / výškové nastavenie



Achtung! Bitte nur Schraubenzieher zu verwenden, keinen Akkuschrauber!
Pozor! Prosím skrutkujte manuálne, nie akuskrutkovačom.



3

