












1



2






3







MI 24


4




5



5A




5B




MI 24

7




4PCS



7A



7B



7C



MI 24

ACHTUNG!

Zur Reinigung der Fronten und des Korpusen verwenden Sie bitte Wasser mit Seife, einen Glasreiniger oder Alkohol

WARNING!

To clean front surface and structure please use water and soap, glass cleaner or alcohol

ОСТОРОЖНО!

Чтобы очистить фасады и структуры мебели, используйте мыло и воду или продукт для очистки стёкол или алкоголя

ATTENTION!

Pour nettoyer les façades et la structure, utilisez de l'eau avec du savon, un nettoyant pour vitres ou de l'alcool.

HUOMIO!

Ovien ja rungon puhdistukseen voidaan käyttää mietoa saippualliuosta tai lasin puhdistukseen tarkoitettua nestettä.

ATTENZIONE!

Per pulire le superfici del mobile, utilizzare acqua e sapone, o soluzione per vetri oppure alcool