






ALLESANO



30 min

cm



PL

INSTRUKCJA MONTAŻU
INSTRUKCJA OBSŁUGI

HU

SZERELÉSI ÚTMUTATÁS
KEZELÉSI UTASÍTÁS

DE

MONTAGEANLEITUNG
BEDIENUNGSANLEITUNG

GB

ASSEMBLY INSTRUCTIONS
INSTRUCTION MANUAL

TR

MONTAJ TALIMATI
KULLANIM KLAVUZU

NL

HANDLEIDING VOOR DE MONTA
GEBRUIKSAANWIJZING

RO

INSTRUCȚIUNI DE INSTALARE
INSTRUCȚIUNI DE UTILIZARE

RU

ИНСТРУКЦИЯ ПО МОНТАЖУ
ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ

SK

MONTÁŽNY NÁVOD
NÁVOD NA POUŽITIE

FR



NOTICE DE MONTAGE
MANUEL INSTRUCTIONS

IT






ISTRUZIONI DI MONTAGGIO
MANUALE DI ISTRUZIONI

CZ





MONTÁŽNÍ NÁVOD
NÁVOD K POUŽITÍ






A B C D E







1



A







2




B



C



3





1






D

A






4





B



C


















5







E









Exxpo DE GmbH
Friedrich- Engels-Str.9
15517 Fürstenwalde/ Spree
exxpo@exxpo-sofa.com