



Assembly Instruction

4300060



Panel No	Panel Sizes	Quantity
1	1200*400*16	1
2	1200*400*16	1
3	268*399*16	1
4	268*399*16	1


Panel No	Panel Sizes	Quantity
5	268*360*16	1
6	572*350*16	2
7	1176*278*5	1
8	587*264*18	1




Fittings



A=6




B=12




C=6




D=6



E=6




F=1



M6*16


G=19




I3=2




H=1




S=1




J-1=4



J-2=1



L=8




U=1



Z1=19




Z2=19




Q=6


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9





STEP 10






STEP 11




STEP 12




STEP 13




STEP 14



STEP 15




STEP 16



Finish

新-利尼单门电视柜W120邮购包装



Panel No		Panel Sizes	Quantity
9	护角	50*50*50	8
10	泡沫	1200*400*10	2
11	泡沫	440*105*40	2
12	泡沫	1200*105*20	2
13	泡沫	1200*132*15	1
14	泡沫	268*252*15	1
15	泡沫	360*90*30	1
16	泡沫	932*50*30	1
17	纸盒	内径1290*450*115	1