




























WALKER OBKL-2FR









A  x2	B  x4	C  x4	D  x2	E  x8	F  x14
		G  x6	H  x1	I  x4	J  x4







A	 x2	B	 x4	C	 x3	D	 x2	E	 x8	F	 x14
				G	 x7	H	 x1	I	 x4	J	 x4

Service – Dienstverlening – Serwis – Servis – Сервисная служба – Assistenza - Szerviz	
Typ – Type – Tip – Тип – Тірүс - Tipo	
A	
B	
C	
D	
E	
F	
G	
H	
I	
J	