
























Benötigte Werkzeuge – Outils Nécessaires – Tools Required – Attrezzi Necessari




D x1  745.293	E x2  745.283	F x2  745.280	G x2  745.281	H x4  745.282	J x20 Ø4x20  631.30300
M x16 Ø8x30  630.02100	R x2  631.95000	S x2  631.08000	T x2  631.61100	U x12 Ø4x16  631.13300	V x2  li 629.00094 re 629.00095
W x2  li 629.00096 re 629.00097	X x8 Ø4x12  631.16300	Y x28 Ø4x35  631.72900	Z x4  629.00111	a x4 Ø3.5x20  631.30000	SW6  631.10300




3.




4.





5.




6.








9.



10.




11.





12.

CLIC



13.



Drücken
To push
Pousser

Schubladen herausziehen
Pull out drawers
Sortir les tiroirs