



ELIAS OTMSTVL-2SR







45 min




D – Montageanleitung
GB – Assembly instructions
NL – Handleiding voor de montage
PL – Instrukcja montażu
TR – Montaj talimatı
RU – Инструкция по монтажу


RO – Instrucțiuni de montaj
IT – Istruzioni di montaggio
FR – Notice de montage
SK – Návod na montáž
CZ – Montážní návod
HU – Szerelési útmutató


					
A x4	B x6	C x8	D x8	E x6	F x1



1







2











A

B

Service – Dienstverlening – Serwis – Servis – Сервисная служба – Assistenza - Szerviz

Typ – Type – Tip – Тип – Tipyс - Tipo

A

B