

WINKEE

Remote Control Fart Sound Machine with 15 different Sounds



Instructions:

1. Install 1 x 9V alkaline battery (not included)
2. Turn the sound unit on
3. Hide the fart machine e. g. under a pillow or seat cushion
4. When an unsuspecting person walks by, press the remote button to trigger a sound

WARNING: Choking Hazard. Small parts. Not for children under 3 years.

Insert 1 x 9V alkaline battery and make sure that the poles are aligned correctly. Remove empty batteries immediately, exchange them completely and dispose environment-friendly. Do not recharge disposable batteries. Please keep the packaging for future reference.

Anleitung:

1. Lege eine 9V Batterie ein (nicht enthalten)
2. Schalte die Soundmaschine an
3. Verstecke die Furzmaschine z. B. unter einem Kissen
4. Drücke auf den grünen Knopf der Fernbedienung sobald jemand den Raum betritt

WARNUNG: Erstickungsgefahr. Verschluckbare Kleinteile. Nicht für Kinder unter 3 Jahren geeignet. Lege eine 9V Batterie ein und achte darauf, dass sie an die richtigen Pole angeschlossen sind. Wechsle leere Batterien sofort und komplett aus und entsorge Sie umweltgerecht. Einwegbatterien nicht aufladen. Bitte bewahre die Verpackung für Kommunikationszwecke auf.

MAGS

MAGS Vertriebs GmbH
Stuttgarter Str. 20
75395 Ostelsheim
Germany
WWW.MAGS-VERTRIEB.DE
Tel: 0049-(0)7033-46668-0



Requires 1 x 9V battery (not included)
Benötigt 1 x 9V Batterie (nicht enthalten)

Item no: 16774



4

MADE IN CHINA