



# Cover for Ooni Karu 16

The durable and waterproof Cover for Ooni Karu 16 allows you to protect Ooni Karu 16 from the elements.



## Storing Ooni Karu 16

Carefully stretch the elasticated cover over Ooni Karu 16 from back to front until your oven is completely covered as in Image 4.

## Care Instructions

Hand wash only. Lightly clean with warm water & mild detergent and air dry. Do not iron, bleach, tumble dry or dry clean.

Pass the buckle beneath Ooni Karu 16 and hook it into the loop on the opposite side. Pull the strap tight.

### ! Caution

Wait until Ooni Karu 16 has completely cooled inside and out before using the Ooni Karu 16 Cover. To avoid danger of suffocation, keep this bag away from babies and children. Do not use this bag in cribs, beds, carriage, or playpens. This bag is not a toy.



[ooni.com](https://ooni.com)