












WALKER 2FL-OBKR













PZ2









 A x2	 B x4	 C x4	 D x2	 E x8	 F x14
		 G x6	 H x1	 I x4	 J x4







A	 x2	B	 x4	C	 x3	D	 x2	E	 x8	F	 x14
				G	 x7	H	 x1	I	 x4	J	 x4

Service – Dienstverlening – Serwis – Servis – Сервисная служба – Assistenza - Szerviz	
Typ – Type – Tip – Тип – Тірүс - Tipo	
A	
B	
C	
D	
E	
F	
G	
H	
I	
J	