STERN
OUTSTANDING
– SINCE 1947 –

MONTAGEANLEITUNG

ASSEMBLY INSTRUCTION

NOTICE DE MONTAGE



BEISTELLTISCH ALLROUND
SIDE TABLE ALLROUND
TABLE BASSE ALLROUND

101294 | 101295
101296 | 101297
101299

STERN
OUTSTANDING
– SINCE 1947 –

			
			

A | 1 x	B | 6 x	C | 1 x	D | 4 x
			

E | 8 x | M 5 x 8	F | 8 x | Ø 16 mm	G | 1 x	

STERN
OUTSTANDING
– SINCE 1947 –

1.	

A | 1 x	B | 6 x				
					





STERN
OUTSTANDING
– SINCE 1947 –

2.

A | 1 x	C | 1 x	D | 4 x	E | 8 x	F | 8 x	G | 1 x
					





STERN
OUTSTANDING
– SINCE 1947 –

MONTAGEANLEITUNG

ASSEMBLY INSTRUCTION

NOTICE DE MONTAGE



BEISTELLTISCH ALLROUND
SIDE TABLE ALLROUND
TABLE BASSE ALLROUND

101294 | 101295
101296 | 101297
101299

V29032023

			
			

A | 1 x	B | 6 x	C | 1 x	D | 4 x
			

E | 4 x | M5 x 18	F | 4 x | M5 x 10	G | 8 x | Ø 16 mm	H | 1 x

STERN
OUTSTANDING
– SINCE 1947 –

1.	

A | 1 x	B | 6 x				
					





STERN
OUTSTANDING
– SINCE 1947 –

2.

C | 1 x	D | 4 x	E | 4 x	F | 4 x	G | 8 x