



ELIAS OTMSTVL-2SR









45 min







D – Montageanleitung
GB – Assembly instructions
NL – Handleiding voor de montage
PL – Instrukcja montażu
TR – Montaj talimatı
RU – Инструкция по монтажу



RO – Instrucțiuni de montaj
IT – Istruzioni di montaggio
FR – Notice de montage
SK – Návod na montáž
CZ – Montážní návod
HU – Szerelési útmutató

					
A x4	B x6	C x8	D x8	E x6	F x1









A

B

Service – Dienstverlening – Serwis – Servis – Сервисная служба – Assistenza - Szerviz

Typ – Type – Tip – Тип – Típus - Tipo

A

B