




DOPPIO RECKL-3SR








* +/- 4 cm







D – Montageanleitung
GB – Assembly instructions
NL – Handleiding voor de montage
PL – Instrukcja montażu
TR – Montaj talimatu
RU – Инструкция по монтажу


RO – Instrucțiuni de montaj
IT – Istruzioni di montaggio
FR – Notice de montage
SK – Návod na montáž
CZ – Montážní návod
HU – Szerelési útmutató



3





 A x7	 B 28 x M6x16	 C x1
---	--	--











Service – Dienstverlening – Serwis – Servis – Сервисная служба – Assistenza - Szerviz

Typ – Type – Тип – Тип – Тип – Tipo

A








B

C







D – Recycling-Anweisungen
GB – Recycling instructions
NL – Instructies voor recycling
PL – Instrukcja recyklingu
TR – Geri dönüşüm talimatları
RU – Инструкции по переработке

RO – Instrucțiuni de reciclare
IT – Istruzioni per il riciclaggio
FR – Instructions de recyclage
SK – Pokyny na recykláciu
CZ – Pokyny k recyklaci
HU – Újrahasznosítási utasítások



D – Bedienungsanleitung
GB – Instruction manual
NL – Gebruiksaanwijzing
PL – Instrukcja obsługi
TR – Kullanım klavuzu
RU – ИНСТРУКЦИЯ ПО
 ЭКСПЛУАТАЦИИ

RO – Instrucțiuni de utilizare
IT – Manuale di istruzioni
FR – Manuel instructions
SK – Návod na použitie
CZ – Návod k použití
HU – Kezelési utasítás



D – Bedienungsanleitung
GB – Instruction manual
NL – Gebruiksaanwijzing
PL – Instrukcja obsługi
TR – Kullanım klavuzu
RU – ИНСТРУКЦИЯ ПО
 ЭКСПЛУАТАЦИИ

RO – Instrucțiuni de utilizare
IT – Manuale di istruzioni
FR – Manuel instructions
SK – Návod na použitie
CZ – Návod k použití
HU – Kezelési utasítás