

the device is in order, use the wire buckle (G) to organize the harness



Installation of Feet

Place 2 feet on top of each of the 2 columns.



Möbel-Kollektion-Schuon

tion of Feet

the M6*14mm (B) nuts with an M4 wrench (F). (Total 8 pieces)



Kollektion-Schuon



All the Frames

g the holes in frame and frame, with the threaded holes in the colu



the Frames

the M6x10 hexagon socket head cap screws (A) with an M4 wrench
(B)



the Side Panels

side panels into the frame, and aligning the holes in the side panels with the holes on the bottom of the frame.



the Side Panels

the M6x14 hexagon socket head cap screws (B) with an M4 wrench (Bcs)




the Connecting Rod

the connecting rod into the installed two table frames and indent the
frames towards the center and adjust to a safe length.



the Connecting Rod

the M6x10 hexagon socket head cap screws (A) with an M4 wrench (B)
the frame and connecting rods.(Total 8 pcs)



the Table Board

table board flat on the ground, with the side with the pilot hole facing the table frame 180 degrees and place it on the table board.




The Table Board

holes on the side panels of the table frame are aligned with the pilot
table board, tighten the ST5x20 self-tapping screws (D) with your own
screwdriver or electric gun. (16 pieces in total)



the Table Board

holes on the side panels of the table frame are aligned with the pilot
le board, tighten the ST5x20 self-tapping screws (D) with your own
er or electric gun. (16 pieces in total)



The Controller and Hand Control

hand controller in a suitable position on any side of the bottom edge to avoid interference with the human body or the seat. The hand controller outward, be fixed with ST5*16 self-tapping screw (E).